


# Technical Specification



**Category:** Switch

**Part Number:** 440019

**Description:** truSmart 4 Button Scene Switch Battery Version SMB, Battery (CR2430) Not Included



## Product Features:

- Sleek Four Button Design
- Simple and User Friendly Set up
- CR2430 battery required (Not Included)

## General information:

Wattage (W) \_\_\_\_\_

## Technical information:

Application Location	Internal
Socket	N/A
Install Options	BESA/Conduit
Replaceable Driver	No
Replaceable LED	No
Maintained	Maintained/Non-Maintained
Sensor Technology	Microwave

