


Technical Specification

Category: Switch

Part Number: 440019

Description: truSmart 4 Button Scene Switch Battery Version SMB,
Battery (CR2430) Not Included



Product Features:

- Sleek Four Button Design
- Simple and User Friendly Set up
- CR2430 battery required (Not Included)

General information:

Wattage (W)

Technical information:

Application Location	Internal
Socket	N/A
Install Options	BESA/Conduit
Replaceable Driver	No
Replaceable LED	No
Maintained	Maintained/Non-Maintained
Sensor Technology	Microwave

